


**Seat Ventilation with Heated Seats , (Q1A),(4D3),(4V0)**

From January 2011

**Audi**

Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

**erWin**



# Left Front Seat Temperature Sensor, Memory Seat/Steering Column Adjustment Control Module, Driver Backrest Heating Element


- G344 Left Front Seat Temperature Sensor
- J136 Memory Seat/Steering Column Adjustment Control Module
- J519 Vehicle Electrical System Control Module
- ST2 Fuse Panel 2
- SD10 Fuse 10 (On Fuse Panel D)
- SB15 Fuse 15 (On Fuse Panel B)
- T6d 6-Pin Connector
- T6h 6-Pin Connector, In the Coupling Point for the Left Front Seat
- T8ab 8-Pin Connector, In the Driver Seat, Brown
- T8ac 8-Pin Connector, In the Driver Seat, Black
- T12x 12-Pin Connector
- T16c 16-Pin Connector
- T16q 16-Pin Connector
- Z6 Driver Seat Heating Element
- Z7 Driver Backrest Heating Element
- Z31 Driver Seat Bolster Heater

- 95 Ground Connection 1 (in Seat Adjustment Wiring Harness)
- 96 Ground Connection 1 (in Heated Seats Wiring Harness)
- 318 Ground Connection 4 (in Heated Seats Wiring Harness)
- 371 Ground Connection 6 (in Main Wiring Harness)
- 639 Ground Connection on Left A-Pillar
- B549 LIN Bus Connection 2 (in Main Wiring Harness)

\* Refer to Applicable Wiring Diagram for Fuse Positions  
\*2 From June 2014

ws = white  
sw = black  
ro = red  
rt = red  
br = brown  
gn = green  
bl = blue  
gr = grey  
li = lilac  
vi = lilac  
ge = yellow  
or = orange  
rs = pink

Memory Seat/Steering Column Adjustment Control Module,  
Driver Seat Backrest Blower Fan, Driver Seat Cushion  
Blower Fan




- |      |   |
|------|---|
| J136 | Memory Seat/Steering Column Adjustment Control Module |
| T3ba | 3-Pin Connector                                       |
| T3bb | 3-Pin Connector                                       |
| T3be | 3-Pin Connector                                       |
| T3bf | 3-Pin Connector                                       |
| T8ac | 8-Pin Connector, In the Driver Seat, Black            |
| T16q | 16-Pin Connector                                      |
| V388 | Driver Seat Backrest Blower Fan                       |
| V390 | Driver Seat Cushion Blower Fan                        |
| V417 | Driver Seat Backrest Blower Fan 2                     |
| V419 | Driver Seat Cushion Blower Fan 2                      |

- 136 Ground Connection 2 (in Heated Seats Wiring Harness)
- 145 Ground Connection 3 (in Heated Seats Wiring Harness)
- M41 Connection 1 (in Driver Seat Wiring Harness)
- M42 Connection 2 (in Driver Seat Wiring Harness)
- M43 Connection 3 (in Driver Seat Wiring Harness)
- M44 Connection 4 (in Driver Seat Wiring Harness)

ws = white  
sw = black  
ro = red  
rt = red  
br = brown  
gn = green  
bl = blue  
gr = grey  
li = lilac  
vi = lilac  
ge = yellow  
or = orange  
rs = pink

Right Front Seat Ventilation Control Module, Front Passenger Backrest Heating Element, Front Passenger Side Heated Seat



- J799 Right Front Seat Ventilation Control Module
- J800 Left Front Seat Ventilation Control Module
- ST1 Fuse Panel 1
- SF9 Fuse 9 (On Fuse Panel F)
- T6i 6-Pin Connector, In the Coupling Point for the Right Front Seat
- T8ah 8-Pin Connector, In the Front Passenger Seat, Black
- T8ai 8-Pin Connector, In the Front Passenger Seat, Brown
- T18e 18-Pin Connector
- Z8 Front Passenger Seat Heating Element
- Z9 Front Passenger Backrest Heating Element
- ZX16 Front Passenger Side Heated Seat
- Z33 Front Passenger Seat Bolster Heater


- 35 Ground Connection Under Front Passenger Seat
- 96 Ground Connection 1 (in Heated Seats Wiring Harness)
- 318 Ground Connection 4 (in Heated Seats Wiring Harness)
- 378 Ground Connection 13 (in Main Wiring Harness)

Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG is not responsible for any damage or liability with respect to the correctness of information derived from this document.

- \*2 For LHD Vehicles
- \*3 For RHD Vehicles
- \*4 For USA Only
- \*5 From April 2013

- ws = white
- sw = black
- ro = red
- rt = red
- br = brown
- gn = green
- bl = blue
- gr = grey
- li = lilac
- vi = lilac
- ge = yellow
- or = orange
- rs = pink






Right Front Seat Temperature Sensor, Right Front Seat Ventilation Control Module, Front Passenger Seat Cushion Blower Fan, Front Passenger Seat Cushion Blower Fan 2, Front Passenger Side Heated Seat

- G345 Right Front Seat Temperature Sensor
- J799 Right Front Seat Ventilation Control Module
- J800 Left Front Seat Ventilation Control Module
- T3bd 3-Pin Connector
- T3bg 3-Pin Connector
- T8ai 8-Pin Connector, In the Front Passenger Seat, Brown
- T18e 18-Pin Connector
- V391 Front Passenger Seat Cushion Blower Fan
- V420 Front Passenger Seat Cushion Blower Fan 2
- Z8 Front Passenger Seat Heating Element
- ZX16 Front Passenger Side Heated Seat
- Z33 Front Passenger Seat Bolster Heater

- 136 Ground Connection 2 (in Heated Seats Wiring Harness)
- 318 Ground Connection 4 (in Heated Seats Wiring Harness)
- M51 Connection 1 (in Front Passenger Seat Wiring Harness)
- M52 Connection 2 (in Front Passenger Seat Wiring Harness)
- O12 Connection 1 (in Heated Seats Wiring Harness)

- \* For LHD Vehicles
- \*2 For USA Only
- \*3 From April 2013
- \*4 For RHD Vehicles

- ws = white
- sw = black
- ro = red
- rt = red
- br = brown
- gn = green
- bl = blue
- gr = grey
- li = lilac
- vi = lilac
- ge = yellow
- or = orange
- rs = pink



Right Front Seat Ventilation Control Module, Front Passenger Seat Backrest Blower Fan, Front Passenger Seat Backrest Blower Fan 2

- J799 Right Front Seat Ventilation Control Module
- J800 Left Front Seat Ventilation Control Module
- T3bh 3-Pin Connector
- T3bi 3-Pin Connector
- T8ah 8-Pin Connector, In the Front Passenger Seat, Black
- T18e 18-Pin Connector
- V389 Front Passenger Seat Backrest Blower Fan
- V418 Front Passenger Seat Backrest Blower Fan 2
- 136 Ground Connection 2 (in Heated Seats Wiring Harness)
- 145 Ground Connection 3 (in Heated Seats Wiring Harness)
- M53 Connection 3 (in Front Passenger Seat Wiring Harness)
- M54 Connection 4 (in Front Passenger Seat Wiring Harness)

\* For LHD Vehicles  
\*2 For RHD Vehicles

Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.

ws = white  
sw = black  
ro = red  
rt = red  
br = brown  
gn = green  
bl = blue  
gr = grey  
li = lilac  
vi = lilac  
ge = yellow  
or = orange  
rs = pink